

PML News – Volume 68 (10/10/06)

Hello there. A quick note for all you CPR3000 owners out there...we've added some important information to our CPR FAQ (and Complete FAQ as well, since it contains all separate FAQs rolled into one). The content we've added is below, and speaks for itself:

=====

IMPORTANT NOTE TO HELP PREVENT BLOWBY DAMAGE:

Through testing we've determined that customer complaints of black powder blowby is attributable in nearly every case to improper/incomplete prep of the charge cylinders.

In all CPR prep instructions there is a step (usually Step C) that states: "**Push a small wad of tissue into the hole using a pointed object. This will seal the hole and keep the black powder from leaking out.**" In our tests we've determined that not performing this step completely is the #1 cause of BP blowby. The wad of tissue referenced must be packed tight and must fill the hole completely. Please take additional care in the future to check and recheck yourself on this important step. If our prep instructions are followed carefully and completely there is very little chance of any significant blowby."

=====

Thanks again for your support of PML! Fly high, and fly safe!

Andy Waddell
PML Online Support Rep